



Suffix No.	Position	Terminal
-01	1 2 3 4 5 6	711
-02	1 2 3 4 6	711
-03	1 3 4 6	711



Suffix No.	Position	Terminal
-04	1 2 3	711
-05	1 3	711
-06	1 2 3 4 5 6	703



Suffix No.	Position	Terminal
-01	1 3 4 6	712
-02	1 2 3	712
-03	1 3	712

Suffix No.	Position	Terminal
-04	1 2 3 4 6	711
-05	1 2 3 4 6	702
-06	1 3	702



EI 21
Part # 3003



Suffix No.	Position	Terminal
-01	1 2 3 4 5 6	711
-02	1 2 3 4 6	711
-03	1 3	711

Suffix No.	Position	Terminal
-04	1 2 3 4 5 6	712
-05	1 2 3 4 6	712
-06	1 3	712

EI 625
Part # 3004



Suffix No.	Position	Terminal
-01	1 2 3 4 5 6	711
-02	1 2 3 4 5 6	712
-03	1 2 3 4 6	712

Suffix No.	Position	Terminal
-04	1 3 4 6	712
-05	1 2 3	712
-06	1 3	712